

## Cloning Other RF30s

By choosing the **Simple Sound Setup** button the user is taken to the following video.

### HOST #1

SimpleSound™ is a dynamic feature that gives you total volume control over all the Components in your system, even those without their own built-in volume control, such as TiVo, DVD and VCR... saving you the hassle and inconvenience of constantly needing to switch between Component modes on the remote. With SimpleSound™, you can set the RF30's volume control buttons to always control the sound in your system, even when you're in VCR or DVD mode, without switching back to AUDIO or TV.

Even more exciting, SimpleSound™ is what is called a 'Punch Through' feature and is not limited strictly to volume control. Now, let's setup SimpleSound™.

Step one, in a basic home entertainment system, the sound may come from your TV. In a more advanced system, the sound may come from your audio Component such as a Surround Sound Receiver or Home Theatre system. So, first, you need to identify which Component you want to use in your system for sound.

Step two, press and hold the MAIN and ENT buttons at the same time for approximately 3 seconds, until the word "SETUP" is displayed at the top of the LCD touch screen. This signals that you are now in setup mode.

Remember, you now have 30 seconds to perform the next step while you are in SETUP mode.

(MORE)

## HOST #1 (cont'd)

If you don't press a button within 30 seconds, SETUP will disappear from the screen, signaling that you have exited setup mode and you will need to start over.

Step three, from the LCD screen Setup menu, press the PUNCH button. Step four, then press the VOL button. The screen will display "VOL" at the top. This sets up the group of three buttons Volume Up, Volume Down and Mute in one action. The bottom of the display flashes "PUNCH TO". Press the button for the Component that doesn't have volume control commands yet like your DVD player. This is the Component you are going to PUNCH TO for the volume and mute commands.

If you want to have volume control on the MAIN Component, press the POWER OFF button at this time.

Step five, the bottom of the display will then flash "PUNCH FROM". Now select the Component that has the volume commands you want to use, such as TV for systems using the TV speakers, or AUDIO for systems with surround sound receivers. The bottom of the display will flash "SAVED".

Step six, repeat STEPS 3-5 until all your Components operate the volume perfectly.

Step seven, press the MAIN button twice to return to normal operating mode and test your SimpleSound™ settings.

The Punch Through feature is not limited to volume and can also be applied to other functions such as Channel, Play, or VOD. Refer to page 31 in your owner's manual about how to program other Punch Through functions.

The user is taken back to the **Content Menu**.

By choosing the **Customizing/Advanced Features** button the user is taken to a second menu.

**Customizing the Touch Screen**

**Favorite Channel Setup**

**MacroPower Setup**

**Simple Sound Setup**

**Setting Backlight Options**

**Hiding & Adding LCD Pages**

**Recalling Pre-programming Setup Code Numbers**

**Cloning Other RF30s**

By choosing the **Setting Backlight Options** button the user is taken to the following video.

#### HOST #2

You can customize the backlighting feature to suit your specific preferences. You can adjust the amount of time that the RF30 backlight stays on, you can make the text darker or lighter, and if you don't want backlighting at all you can turn it off which extends battery life. Refer to page 32 in your owner's manual for more information.

The user is taken back to the **Content Menu**.

By choosing the **Customizing/Advanced Features** button the user is taken to a second menu.

**Customizing the Touch Screen**

**Favorite Channel Setup**

**MacroPower Setup**

**Simple Sound Setup**

**Setting Backlight Options**

**Hiding & Adding LCD Pages**